

**HIGH PRECISION BALANCE**

# **MWP**

## **OWNER'S MANUAL**



**MWP-2004-12 ver.1.0**

<b>INTRODUCTION</b>	<b>1</b>
<b>1. INSTALLATION</b>	<b>2</b>
Unpacking	2
Illustration of the installation for plastic shield	2
Selecting the Location	3
Leveling the scale	3
Connecting Power	3
AC power	3
Battery power	4
2.6 Initial Calibration	4
<b>2. OVERVIEW OF DISPLAY INDICATORS AND KEYBOARD FUNCTIONS</b>	<b>5</b>
Display Symbols	5
Keyboard Functions	6
<b>3. OPERATIONS</b>	<b>7</b>
Weighing mode	7
4.1.1 Units Selection	7
4.1.2 Zero Function	7
4.1.3 Tare Function	7
4.1.4 Over load alarm	8
4.2 Counting mode	8
4.3 Percentage (%) mode	9
<b>4. PARAMETER SET-UP</b>	<b>10</b>
Calibration	11
To choose the initial unit while turning on	12
To choose the "UNIT" you need	13
To choose the time of AUTO OFF	14
To choose output transmission method	15
Baud rate setting for RS232 interface	16
To choose the range of stability	17
To choose the Zero display range	18
To choose the Zero Recovery display range	19
To choose the auto-average in sampling on counting mode	20
To choose Backlight mode	21
<b>5. AUTO CALIBERATION</b>	<b>22</b>
<b>6. RECOVERY OF THE DEFAULT VALUES FROM MEMORY</b>	<b>22</b>
<b>7. ERROR MESSAGES</b>	<b>22</b>
<b>8. SPECIFICATION OF RS-232 INTERFACE</b>	<b>23</b>
<b>9. CONVERSION UNITS TABLE FOR WEIGHTS</b>	<b>25</b>
<b>10. TABLE LIST FOR FULL CAPACITY</b>	<b>25</b>
<b>12. TECHNICAL DATA</b>	<b>26</b>

## **1. INTRODUCTION**

The scale is very simple to use and are applicable for general weighing. The user can also use the parts counting and percent weighing functions for special applications. Special functions are available for weighing in up to 8 different units of weight.

For safe and dependable operation of this scale, please comply with the following **safety precautions**:

- Verify that the input voltage printed on the AC Adapter and the plug type matches the local AC power supply.
- Make sure that the power cord does not pose a potential obstacle or tripping hazard.
- Disconnect the scale from the power supply when cleaning the scale.
- Do not operate the scale in hazardous or unstable environments.
- Do not immerse the scale in water or other liquids.
- Do not drop loads on the platform.
- Use only approved accessories and peripherals, as available.
- Operate the scale only under ambient conditions specified in these instructions.
- Service should be performed by authorized personnel only.
- It must not be bump against other items or overloaded with excessively heavy weights (The load must not exceed the maximum capacity of the balance).

## 2. INSTALLATION


### 2.1 Unpacking

Unpack and verify that the following components have been included:

- Scale
- Steel pan
- Instruction Manual
- AC Adapter
- CD-ROM (for the scale with USB interface only)
- USB Cable (for the scale with USB interface only)
- Five pieces of wind shield

Save the packaging material. This packaging ensures the best possible protection for the storage or transport of the product.

### 2.2 ILLUSTRATION OF THE INSTALLATION FOR PLASTIC SHIELD



## **2.3 Selecting the Location**

Operate the scale on a firm, level surface. Avoid locations with rapid temperature changes, excessive dust, moisture, air currents, vibrations, electromagnetic fields, heat or direct sunlight.

## **2.4 Leveling the scale**

Adjust the leveling feet until the bubble is centered in the circle of the level indicator(located on the front panel).

**NOTE:** Ensure that the scale is level each time its location is changed.

## **2.5 Connecting Power**

### **2.5.1 AC Power**

Verify that the intended AC power source matches the AC adapter rating. Connect the supplied AC adapter to the power input receptacle at the back of the scale. Plug the AC adapter into a properly grounded power outlet.

## 2.5.2 Battery Power

The battery will begin charging with the AC adapter connected accordingly. An LED indicator below and to the left of the scale shows the status of battery charging:

- Green-battery is fully charged
- Yellow-battery is partially charged and charging
- Red -battery is nearly discharged

When AC power is not available, the scale will operate on the internal rechargeable battery. The scale will automatically switch to battery operation if there is a power failure or the power cord is removed. Low battery charge is indicated by the  annunciator.

Before using the scale for the first time, the internal rechargeable battery should be fully charged for up to 12 hours. A fully charged battery can operate the scale for approximately 80 hours independent of AC power. The battery is protected against overcharging and the scale can remain connected to the AC power line.

### **NOTE:**

- The battery must be recharged every 3 months if the scale is not used for a long time.
- Dispose of the lead acid battery according to local laws and regulations.


## 2.6 Initial Calibration

When the scale is operated for the first time, a Span Calibration is recommended to ensure accurate weighing results. Before performing the calibration, be sure to have the appropriate calibration weights.

Refer to Section 5.1 for Span Calibration procedures and Section 6 for AUTO CALIBRATION.

### 3. OVERVIEW OF DISPLAY INDICATORS AND KEYBOARD FUNCTIONS

#### 3.1 Display Symbols



1	<b>Zero-</b> Is displayed when the “Zero” key is pressed.
2	<b>Tare-</b> Is displayed when the “Tare” key is pressed.
3	<b>Stable-</b> Stable indication, scale is in stable condition.
4	<b>Mode-</b> Is displayed when the “Mode” key is pressed.
5	<b>Setup-</b> Is displayed when the “Setup” key is pressed.
6	<b>CAL-</b> Is displayed when the scale in Calibration Mode.
7	▣▣▣▣ - Power indication.
8	<b>Use      key to change-</b> Used to prompt the user while navigating through the menu system.
9	<b>Press Enter</b> –Used as a prompt to the user to press the Enter key. The menu item displayed is selected.
10	<b>Press Esc-</b> Used as a prompt to the user to press the Esc key to return to last menu or exit Setup Mode.
	<b>Symbols for weighing units and modes, include:</b>
11	ct      <Left><Right>-ats lb      <Left><Right>-unds oz    -Ounces GN    -Grain ozt    -Ounces troy dwt    -Pennyweight t1.T    -Tael pcs    -Parts counting %      -Percent weighing °C     -Temperature

### 3.2 Keyboard Functions



: ON/OFF switch



: Function key to choose weighing, counting, percentage



: "Unit" selection, 8 units are available



: Sample key to set the unit weight of sample



: Tare key to deduct the container weight



: Zero key, press this key, the weight will become "0"



: Confirmation key and print key



: Selects various menus



: Return to last menu or exit Setup Mode



: Travels to the left through menus



: Travels to the right through menus



: Travels up through menus



: Travels down through menus

## 4. OPERATIONS

Press the  key for power on, the scale will be on the weighing mode using the initial units of weight selected.

### 4.1 WEIGHING MODE

#### 4.1.1 Units selection

Press the  key to choose the weighing units and the display will be changed to the new value with the units shown. There are up to 8 units of weight that can be enabled.

#### 4.1.2 Zero Function

If the zero shifts during operation, press the  key to set it to zero. The Zero function is only active over  $\pm 2\%$  of full capacity.

#### 4.1.3 Tare Function

Tare weight is the weight of a container and can be subtracted by placing an empty container on the scale. When the display is stable, press the  key. The display will become zero and the display will have a tare indication.

Cancel the tare function by pressing the  key with no weight on the scale.

Tare range is the full capacity of the scale.

#### 4.1. 4 Over load alarm

When the weight on the scale is more than Max. capacity, the display shows "----OL-----" at the same time the buzzer sounds. Please take off the weight at once. Otherwise the scale will be easily damaged.

#### 4.2 COUNTING MODE

The scale will count parts by weighing a preset number of samples and setting the display to show the number. Then, as more samples are added, the display will increase. If necessary, place a container on the scale and press  key before beginning.

After selecting parts counting with the  key, press the  or  ,  key to select the sample size (10,20,50,100 pcs).

Put the sample number (same as selected) on the scale and press  key. When the symbol "C" disappears the sampling procedure is finished and you can start to use the counting function.

If the unit weight is too small (less than 0.2 of a scale division), the display will show: "----or----pcs." It would be best to use larger parts or to use ten times as many parts as required and reduce the displayed values to 1/10th.

### 4.3 Percentage (%) mode

After selection % Weighing with the  key press the  or ,  key to choose either 100.0%, 100.00%.

Put the item to be considered 100% onto the pan and press the  key to sample, at the same time the symbol "Mode" flash, after several seconds the symbol "Mode" disappears and the buzzer sounds the sampling procedure is finished and you can start to use the percentage function.

When the value of the sample is smaller than 0.2d, the display will show "----or----". It means that the sample is too small, larger parts should be put on.

#### NOTE:

- When you finish the procedures of selecting the sample size in the counting mode or percentage(%) mode, press the  key to change back to the weighing mode.


Press the  key to return to counting or percentage mode.

The scale will memorize the previous data automatically so that you can continue to count parts or weigh in percentage.

- The memory of sampling size data will be cleared automatically when the two modes of counting and percentage switch reciprocally.


## 5. PARAMETER SET-UP

Press **Setup** key to enter SETUP PARAMETER mode during in weighing mode, and the display shows "CAL". The functions will change by pressing **◀** , **▶** key. The functions are:



## 5.1 Span Calibration

When the display shows “CAL”, press the  key to enter Auto calibration.




Please use ,  and ,  key to key in the mass values which you are going to calibrate, then press  key to confirm the value. When the display is flashing and showing the weight values, put the mass on scale. While scale is stable, the scale will return back to weighing mode. The calibration procedure is finished.

- NOTE:**
- **Mass Value:** Any over (full calibration  $\times$  10%) weight of key in value is acceptable to calibrate.
  - **Suggestion:** Generally. If the calibrated weight is over half load capacity or full load capacity, it will be good for getting the precise accuracy.  
Another method for auto calibration, please see the section 6 “AUTO CALIBRATION”.
  - During in calibration procedure, you can press the  key to exit calibration function.

## 5.2 To choose the initial unit while turning on

Please press **Units** or **▲**, **▼** key to select the unit, then press **Enter** key to confirm. Press **Esc** key to return to last menu or exit.  
(Factory setting: "g")




### 5.3 To choose the "UNIT" you need (Total 8 units, you can choose some of them you need to use )

Press **Units** or **▲** , **▼** key to move the units, press **◀** , **▶**

key to choose "ON" or "OFF" and press **Enter** key to confirm . Press **Esc** key to return to last menu or exit.


(Factory setting: total 8 units are on)



## 5.4 To choose the time of AUTO OFF

Press  ,  key to select the time of auto off .i.e.no,2,5 or 8 minutes,then press  key to confirm. Press  key to return to last menu or exit.


(Factory setting: "no")



## 5.5 To choose output transmission method

Press ,  key to select "stable transmit", press  key to confirm. Press  key to return to last menu or exit.

(Factory setting: "close")



"CLOSE"=output disabled

"stb"= Stable transmit

"tb"= Transmit by pressing  key


"ser"= Series transmit

"disp"= Transmit the display data

## 5.6 Baud rate setting for RS232 interface

Use ▲ , ▼ key to select the baud rate you need 1200,2400,4800, 9600, Press Enter key to confirm. Press Esc key to return to last menu or exit.

(Factory setting:2400)






## 5.8 To choose the Zero display range

Press  ,  key to select the zero display range from 0 to 3 Divisions, then press  key to confirm. Press  key to return to last menu or exit.


(Factory setting: "1")



## 5.9 To choose the Zero Recovery display range

Press  ,  key to select the display range of zero recovery from 0 to 3 divisions, press  key to confirm. Press  key to return to last menu or exit.


(Factory setting: "2")



## 5.10 To choose the auto-average in sampling on counting mode

Please  ,  key to select the auto-average (Yes or No). Then press  Key to confirm. Press  key to return to last menu or exit.


(Factory setting: "YES")



## 5.11 To choose Backlight Mode

Please  ,  key to select the backlight mode (1,2,3 can be chosen). Then press  Key to confirm. Press  key to return to last menu or exit.

(Factory setting: bl.1)



“bl.1”=Auto backlight

“bl.2”=Backlight will always be on

“bl.3”=No backlight

## **6. AUTO CALIBRATION**

Press the  key for about 3 seconds. The display will show the “Calibration weight value.” Put the same weight on the pan. When the “CAL” symbol disappears, the calibration procedure is finished.

## **7. RECOVERY OF THE DEFAULT VALUES FROM MEMORY**

During in weighing mode, hold down the  key for 3 seconds. The scale will come back with a default calibration values.

## **8. ERROR MESSAGES**

During self test the scale verifies operation and the load cell.

Error messages are: “ E 1 . E 2 . E 5 . 0 L ” messages.

These messages may also be shown if the pan is not installed correctly or the environment is not suitable.

Contact your dealer for assistance.

## 9. SPECIFICATION OF OUTPUT INTERFACE

**Mode:** EIA-RS-232 C's UART signal, or USB signal.

**Format:**

Baud rate: 2400 BPS ,4800 BPS  
 Data bits: 7 BITS  
 Parity bit: 1 EVEN  
 Stop bit: 1 BIT  
 Code: ASCII

RS-232 connector is a 9 pin D-subminiature socket.

Input Pin 2  
 Output Pin 3  
 Signal Ground Pin 5



**DATA FORMAT:**

HEAD1	HEAD2	DATA	UNIT	CR
1 2	3 4 5	6 7 8 9 10 11 12 13 14	15 16 17 18	19 20
HEAD1 (2 BYTES)		HEAD2 (2BYTES)		
OL-Overload,		NT-NET Mode		
ST-Display is Stable		GS-Gross Weight		
US-Display is Unstable				
DATA(8BYTES)				
2D (HEX)="-"(MINUS)		20(HEX)=" "(SPACE)		
2E (HEX)="."(DECIMALPOINT)				
UNIT(4BYTE)				
g-20 (HEX); 20 (HEX); 20 (HEX); 67 (HEX)				
lb-20 (HEX); 20 (HEX); 6c (HEX); 62 (HEX)				
TI.T-74 (HEX); 6C (HEX); 2E (HEX); 54 (HEX)				

**Transmit Example:**

EX+0.876g,when it is stable and net value as:

HEAD,	HEAD,	DATA	UNIT	CR
ST ,	NT ,	+ 0.876	g	0D 0A

EX-1.568lb, when it is unstable and net value as:

HEAD,	HEAD,	DATA	UNIT	CR
US ,	NT ,	- 1.568	lb	0D 0A

EX+15.24tl.T,when it is stable and net value as:

HEAD,	HEAD,	DATA	UNIT	CR
ST,	NT ,	+15.24	tl.T	0D 0A

<b>10. CONVERSION UNITS TABLE FOR WEIGHTS</b>
---

1 ct (MET.CARAT)	=0.1999694	g
1 lb(AVOIRDUPOIS POUND)	=453.59237	g
1 oz(AVOIRDUPOIS OUNCE)	=28.349523125g	
1 GN(GRAIN)(U.K)	=0.06479891	g
1 ozt (TROY OUNCE)	=31.1034768	g
1 dwt(PENNYWEIGHT)	=1.55517384	g
1 tl.T(TAEL)(TWN)	=37.799375	g

<b>11. TABLE LIST FOR FULL CAPACITY</b>
---

	150g× 0.005g	300g× 0.01g	600g× 0.01g	1500g× 0.05g	3000g× 0.1g
g	150.045	300.09	600.18	1500.45	3000.9
ct	750.18	1500.45	3000.9	7501.8	15004.5
lb	0.33018	0.66045	1.3009	3.3018	6.6045
oz	5.2018	10.5045	21.009	52.018	100.045
GN	2300.9	4601.8	9204.5	23009	46018
ozt	4.8018	9.6045	19.009	48.018	96.045
dwt	96.045	190.09	380.18	960.45	1900.9
tl.T	4.0018	8.0045	16.009	40.018	80.045

## 12. TECHNICAL DATA

Capacity x Readability	150X 0.005g	300X 0.01g	600X .02g	1500X 0.05g	3000X 0.1g	300X 0.005g	600X 0.01g	1200X 0.02g	3000x 0.05g
Maximum Displayed Resolution	1:30000	1:30000	1:30000	1:30000	1:30000	1:60000	1:60000	1:60000	1:60000
Construction	ABS plastic, stainless steel platform								
Tare range	Full capacity								
Zero range	$\cong \pm 2\%$ of full capacity								
Weighing Units	G, ct, lb, oz, GN, oz t, dwt, tl, T								
Application Modes	Weighing, Counting and percentage (%)								
Display	6 digits LCD (40X95mm) with auto backlight								
Stabilization time	$\cong 2$ seconds								
Operating Temperature	0 to 40°C / 32 to 104°F								
Humidity Range	$\cong 90\%$ relative humidity, non-condensing								
Power	AC Adapter 12V DC/500mA & Internal rechargeable lead acid battery								
Calibration	Automatic external								
Battery life	80 hours continuous use with 12 hours recharging time								
Interface	RS-232 or USB output(Optional)								
Pan Size	150g~600g : $\varnothing 116$ mm (round) 1200g ~ 3000g: 124X144mm (square)								
Scale Dimensions (WxHxD)	200X80X250mm								